Safety and Precautions

Before using the device, please read this instruction carefully in avoidance of any potential dangers or operations that may cause faults to the product.

Usage Environment

Do not place the product in dusty and humid environments in case of internal circuit fault.

Do not place the product near heating devices (such as electrical heater).

Children Safety

The product and accessories may contain some tiny components. Please place them beyond the reach of children in avoidance of swallowing danger.

Waterproof Function

The product is not waterproof, Please keep it dry.

Maintenance and Care

Maintenance of this product should be only performed by qualified technicians.

Do not insert any sharp objects into this product.

Please avoid of intense hit or drop on the product .

Cable

This product is recommended to match standardized USB cable.

Statements

1. Copyright ownership of hardware and software design belongs to Guangzhou Shirui Electronics Co., Ltd., shall not be reproduced, copied, or used in other ways without permission. Otherwise Guangzhou Shirui Electronics Co., Ltd. will have the right to pursue legal responsibilities.
2. The image shown in this manual is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern.

Button and Interface

a. USB type A: connect with the PC
b. Button: click to present/stop to present the screen and sound
c. USB type B: connect with the standarlized USB cable

Connection Instructions

This product needs to be used with the Interactive Flat Panel (IFP) .

Step 1:

For the first-time use, connect the EasiCable to your PC and operate the driver manually (the driver will run automatically along subsequent connection).

Step 2:

Step 3:

Click the button to share your screen and sound, when your PC pops out a prompt "Sharing is available".

Instruction of the state indicator

Blinking indicates the device is on to way to be connected.

Lighting indicates the device has already been connected.

Function Introduction

1. Supports to present the screen and sound of your PC to the IFP.
2. Supports to present the screen and sound of your PC to the IFP as an extended screen.
3. Supports to control your PC from the IFP side.

Troubleshooting

When the device cannot be connected, please have a check as following:

1. Confirm whether the driver of EasiCable has been installed on the PC.
2. Confirm whether the USB cable has been correctly connected to the IFP.
3. Try again to connect the Easicable.